

All Geofire door holders are supplied with a keeper plate as standard but an alternative design can be supplied to suit the installation. All keeper plates are also available as spare parts.

The low profile keeper plate may be used when it is desirable to minimise the distance from the held-open door to magnet.

A chain keeper is also available and may be used where the door will not open back to the wall. The chain keeper will bridge the gap from the open door to where the magnet is mounted. See chain keeper datasheet.

Item	Holding force	Adjustment	Order code
Low profile keeper plate	200N	15 °	2-31-0307-N237
Adjustable keeper plate	200N	30 °	2-31-0310-U005
Adjustable keeper plate	500N	30 °	2-31-0507-U001
Low profile keeper plate	500N	15 °	2-31-0507-Z011

KEEPER PLATES:

